

THE WRIGHT

1,756 SQUARE FEET · 3 BED ROOM · 2.5 BATH · STUDY · 1 CAR DETACHED GARAGE
 Frank Lloyd Wright remains the most prominent and influential architect of the early 20th century. Working from 1887 to 1959, Wright's influence can be felt in homes of many periods with Prairie, Arts and Crafts, and decidedly modern and "Wright-esq" designs.

